

PRESTIGE LIGHTED EDITION

WI-FI LIGHTING QUICK-START GUIDE

Setup and operating instructions for power, app control, dimming, schedules, and optional voice control.

Getting Started

No tools or wiring are required.

- 1. Position the Plaque**
Place it on a stable, dry indoor surface near an electrical outlet.
- 2. Connect the Power**
Insert the round plug from the included 12-volt power supply into the connection on the display base.
- 3. Plug It In and Switch It On**
Plug the power supply into a standard indoor outlet. Turn on the switch located on the display base.

Wi-Fi setup is optional. The plaque can always be used with its regular switch.

Download the App

The same instructions apply to iPhone and Android.

- 1. Open Your App Store**
Use the Apple App Store on an iPhone or Google Play Store on an Android phone.
- 2. Install Magic Home Pro**
Install and open the app. Create an account or sign in. Allow local-network access if your phone asks for permission.

Before You Continue

Before continuing, connect your phone to your home Wi-Fi and keep the plaque switched on.

Connect to Wi-Fi

Have your home Wi-Fi password ready.

- 1. Add a Device**
Open Magic Home Pro and tap the "+" or Add Device button.
- 2. Follow the App Instructions**
Add a new Wi-Fi lighting device.
- 3. Connect to LEDnet if Requested**
If asked, connect your phone to a network beginning with "LEDnet," then return to the app.
- 4. Select Your Home Network**
Choose your regular home Wi-Fi network and enter its password.

5. Wait for Confirmation

Wait for the app to confirm that the plaque is connected.

For smart control, leave the base switch ON. You can then use the app to turn the light on or off.

Using the Light

Once connected, choose a recognizable name such as "Prestige Plaque."

From the App You Can

- Turn the light on or off
- Adjust the brightness
- Set automatic on-and-off schedules

App-Only Features

Dimming and schedules are available only through the app.

Using It Without Wi-Fi

Plug in the power supply and use the switch on the display base. The app is not required for basic on/off use.

Important

Leave the base switch on whenever you want to control the light through the app.

Troubleshooting

Light Does Not Turn On

Check the round plug, wall outlet, and base switch.

App Cannot Find the Plaque

Move closer, confirm Wi-Fi is on, and restart the app.

Connection Still Fails

Use a 2.4 GHz Wi-Fi network. Unplug the plaque for 10 seconds and try again.

Wi-Fi Name or Password Changed

Repeat the setup process in Magic Home Pro.

Safety

- Use only the included 12-volt power supply.
- Indoor use only. Keep all parts dry.
- Unplug the plaque before cleaning or moving it.

Optional Voice Control

For Alexa, Google Assistant, SmartThings, or IFTTT, open Magic Home Pro, select "Third-Party Services," and follow the on-screen setup instructions.